

PARTS LIST

Clarke – CDP104B/451F DRILL PRESS	Part Number: - 6505570/580
--	-----------------------------------

<u>Quantity</u>	<u>Description</u>	<u>Part Number</u>
1	BELT TENSION LOCKING SCREW	DD1610205
1	SCREW SET M10	4030430
1	BELT TENSION LEVER	DD16102004
	STOP PIN	DD16104010
1	DEPTH STOP COLLAR W/SCALE	DD16104003
1	DEPTH LOCKING SCREW	DD16104012
1	SPINDLE FEED SHAFT	DD16104000
1	SCALE GUIDE	DD16104004
1	KNOB	DD16104011
1	FEED HANDLE	DD16104005
1	LOCKWASHER	DDGB862187
1	PAN HD. SCREW M5	3040485
1	SWITCH BOX	DD16102008A
1	ON/OFF SWITCH ASSY.	DDKJD12A
1	PAN HD. SCREW	DDGB84585
1	LIGHT SWITCH	DDRF1001
1	LEAD	DD16102018A
1	SPECIAL SL SCREW	DD16102021
	HEX NUT M10	3040602

Parts and Servicing

For parts and servicing, please contact your nearest dealer or CLARKE International on the following number; 020 8988 7400 or e-mail as follows; parts@clarkeinternational.com or service@clarkeinternational.com

1	QUILL SPRING SEAT	DD16104006
1	QUILL SPRING RETAINER	DD16104007
1	QUILL SPRING	DD16104009
1	SPRING CAP	DD16104008
1	HEX NUT	DDGB17286
1	HEAD W/POINTER AND TRIM	DD16102001
1	BULB SOCKET	DD16202013B
1	HEX WRENCH 5MM	DDGB535686C
1	HEX WRENCH 3MM	DDGB535686A
1	CABLE TIE	DD16102017
1	POWER CABLE W/PLUG	DD161020151
1	CONNECTOR WIRE	DD16102019
1	PAN HD. SCREW M6	304020
1	CABLE CLAMP	DD16102014
1	PAN HD. SCREW M5	3040656
1	MOTOR SUPPORT BRACKET	DD16102002
1	HEX HD. SCREW M5	3040502
1	WASHER	DDGB79285
1	MOTOR MOUNT	DD16102007A
1	MOTOR CABLE	DD16102016B
1	HEX. NUT M8	3040601
1	MOTOR ASSY.	DDYL712403
1	HEX NUT M12	3040603
1	LOCK WASHER	DDGB9387
1	MOTOR SUPPORT BRKT.	DD16102002
1	HEX HD. SCREW M8	3044500
1	ADJUSTING LEVER	DD16102006

Parts and Servicing

For parts and servicing, please contact your nearest dealer or CLARKE International on the following number; 020 8988 7400 or e-mail as follows; parts@clarkeinternational.com or service@clarkeinternational.com

1	LEAD	DD16102029
1	LOCK NUT	DD16103005
1	LOCKWASHER	DD16103004
1	FLAT WASHER	DD16103003
1	BEARING 60203	BRG60203
1	O-RING	DD16103006
1	QUILL	DD16103002
1	CHUCK KEY	DD16103010
1	CHUCK JT3	DDJ2216
1	ARBOUR MT2- JT3	DD20120
1	WEDGE DRIFT	DD16103008
1	SPINDLE	DD16103001
1	BEARING 80204	BRG80204
1	CHUCK GUARD	DD16108001
1	CIRCLIP	DD16102024
1	BEARING 60204	BRG60204
1	BEARING SPACER	DD16102023
1	V BELT	DD16201511
1	PULLEY NUT	DD16102025
1	PULLEY SPINDLE	DD16105009B
1	PULLEY INSERT	DD16102022
1	PULLEY COVER W/LABELS	DD16105000
1	RD. HD. SCREW M6	3040650
1	SET SCREW M8	3040528
1	MOTOR PULLEY	DD16205005
1	KNOB	DD16105008
1	PAN HD. SCREW M5	3040656
1	IDLER PIVOT	DD16205007

Parts and Servicing

For parts and servicing, please contact your nearest dealer or CLARKE International on the following number; 020 8988 7400 or e-mail as follows; parts@clarkeinternational.com or service@clarkeinternational.com

1	IDLER PULLEY	DD16205006
1	BEARING 60202	BRG60202
1	FOAM WASHER	DD13105009
1	MICROSWITCH	DDXN5
1	MICROSWITCH COVER	* SEE DEALER
1	HEX, SKT. SCREW SET	3040487
1	RACK COLLAR	DD16101011
1	HELICAL GEAR	DD16101006
1	CRANK	13201009
1	TABLE	SS16101014B
1	TABLE CLAMP	DD16101013
1	TABLE TILR LCKG. SCREW M16 X 35	3040440
1	ARM W/SCALE	DD16101005
1	BASE	DD16101001
1	COLUMN SUPPORT	DD16101002/002B
1	HEX, SKT. SCREW SET M10 X40	3040508
1	HEX, SKT. SCREW SET M10X 12	3040430
1	COLUMN	DDC16101003/003B
1	RACK	DD1610100010
1	ARM LOCKING HANDLE	DD16101012
1	TABLE SUPPORT W/INDICATOR	DD16101004
1	WORM	DD16101008
1	GEAR PIN	DD16101007

Parts and Servicing

For parts and servicing, please contact your nearest dealer or CLARKE International on the following number; 020 8988 7400 or e-mail as follows; parts@clarkeinternational.com or service@clarkeinternational.com

Parts and Servicing

For parts and servicing, please contact your nearest dealer or CLARKE International on the following number; 020 8988 7400 or e-mail as follows; parts@clarkeinternational.com or service@clarkeinternational.com

Parts and Servicing

For parts and servicing, please contact your nearest dealer or CLARKE International on the following number; 020 8988 7400 or e-mail as follows; parts@clarkeinternational.com or service@clarkeinternational.com



Parts and Servicing

For parts and servicing, please contact your nearest dealer or CLARKE International on the following number; 020 8988 7400 or e-mail as follows; parts@clarkeinternational.com or service@clarkeinternational.com

Parts List for Clarke P/N CDP401B/451F DRILL PRESS 6505570/6505580

. Date Issued;